


Metrologic Configuration Bar Codes


Please scan the codes in the numbered order.

1. Enter Program Mode




999999

2. Programmable Suffix 1




80451260

3. Disable Line Feed




116602

4. Disable Carriage Return



116603

5. Exit Program Mode



999999